

The **BIG SPLASH**


Set-Up & Safety Instructions



1 800 637-3656


www.twisterdisplay.com

Parts List



Tee Fitting

Quantity: 1



Corner Fitting

Quantity: 2




Four-Way Fitting:

Quantity: 2



36" Pipe: Quantity-4



Trigger Unit:

Quantity-1



44.5" Tapered Pipe: Quantity-3




41.5" Pipe: Quantity-5



Bucket Assembly:


Quantity-1




Target Cross Brace: Quantity-1



Collar: Quantity-1



Target Arm: Quantity-1



**Filler Tube Hook:
Quantity-1**



Target: Quantity-1



**Filler Tube:
Quantity-1**



**Filler Tube
Clips:
Quantity-3**



**Sponge Balls:
Quantity-12**



**Vinyl Canvas:
Quantity-1**



Step 1

Slide the bucket assembly onto the trigger unit. Make sure that it is positioned so that the roller engages with the trigger hook.



Step 2

Slide on the collar and tighten.



Step 3

Slide on a corner fitting and tighten.






Step 6

Insert filler tube hook and tighten.

Step 7

Use the clips to route the filler tube along the frame to wherever you are going to run the garden hose.




Step 8

Attach the canvas to the frame with the Velcro straps.

Step 9

Attach the garden hose to the connector/valve.



Safety Instructions

- ◆ **Never use baseballs or hard balls. (Use only the balls provided.)**
- ◆ **Set up on level ground.**
- ◆ **Keep Big Splash staked and/or sandbagged for stability.**
- ◆ **Keep Big Splash away from electricity.**
- ◆ **Never stand under the bucket when in use.**
- ◆ **Do not allow anyone to climb on or lean against the Big Splash.**
- ◆ **Do not allow anyone to hit the target with their hand.**
- ◆ **Take down the Big Splash if there is high wind or chance of lightening.**

1 800 637-3656

www.twisterdisplay.com

Big Splash Replacement Parts

Bucket Assembly — \$38

Canvas — \$199

Collar — \$8

4-Way Fitting — \$12

Filler Tube — \$22

Filler Tube Clip — \$15

Filler Tube Hook — \$18

Pipe 36" — \$8

Pipe 41.5" — \$10

Pipe 44.5" (tapered) — \$12

Target — \$18

Target Arm — \$40

Target Cross Brace — \$38

Sponge Ball — \$2 (each)

Trigger Unit — \$60

1 800 637-3656

www.twisterdisplay.com